







Digital SLR Cameras (as of May 2017)		(Sensor)	Format	Camera Crop Factor	Approximate	Model	Lens Description																												
							B001	B005	A16	A14	C001	B011-S	B011-C	B018	B008	B016	A012	A007	A09	A010	A20	A001	A009	A17	A005	A011	F016	F012	F013	G005	27ZE	F017	B01		
Panasonic	GH series	Micro 4/3	2x	SP 10-24mm F/3.5-4.5 Di-II	SP 17-50mm F/2.8 XR Di-II VC	SP 17-50mm F/2.8 XR Di-II	18-200mm F/3.5-6.3 XR Di-II	14-150mm F/3.5-5.8 Di-III for Micro Four Thirds mount only	18-200mm F/3.5-6.3 Di-III for Sony E mount only	18-200mm F/3.5-6.3 Di-III for Canon EOS-M mount only	18-200mm F/3.5-6.3 Di-II VC	18-270mm F/3.5-6.3 Di-II VC PZD	16-300mm F/3.5-6.3 Di II VC PZD	SP 15-30mm F/2.8 Di VC USD	SP 24-70mm F/2.8 Di VC USD	SP 28-75mm F/2.8 XR Di	28-300mm F/3.5-6.3 Di VC PZD	28-300mm F/3.5-6.3 XR Di VC	SP 70-200mm F/2.8 Di	SP 70-200mm F/2.8 Di VC USD	70-300mm F/4-5.6 Di	SP70-300mm F/4-5.6 Di VC USD	SP150-600 F/5-6.3 Di VC USD	SP 85mm F/1.8 Di VC USD	SP 35mm F/1.8 Di VC USD	SP 45mm F/1.8 Di VC USD	SP 60mm F/2 Di-II	SP 90mm F/2.8 Di	SP 90mm F/2.8 Di VC USD	SP 180mm F/3.5 Di					
Panasonic	GH series	Micro 4/3	2x	■	☑	☑	☑	■	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑				
Pentax (Ricoh)	*Ist D / DL / DS series	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	☑	■	☑	☑				
Pentax (Ricoh)	K100D /K100D Super	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K110D	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K10D	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K200D	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K20D	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K30	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K2000 (K-m)	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K-7	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K-x	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K-r	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K-5 series	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K-S2 / K-S1	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K-3 / K-3 II	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K-50	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K-500	APS-C	1.5x	■	☑	■	■	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Pentax (Ricoh)	K-1	Full-frame	—	×	☑	×	☑	☑	☑	☑	☑	☑	☑	☑	■	☑	☑	☑	■	☑	■	☑	☑	☑	☑	☑	☑	■	☑	☑					
Olympus	Pen-E Series / EM Series	Micro 4/3	2x	☑	☑	☑	☑	■	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑					
Olympus	OM-D series	Micro 4/3	2x	☑	☑	☑	☑	■	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑					
Sony	α99	Full-frame	—	×	☑	×	×	☑ <sup>7</sup>	☑ <sup>7</sup>	☑ <sup>7</sup>	×	×	☑	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■	☑	■	■	■	■	■	■	■	■	×	■	■	■					
Sony	α900	Full-frame	—	×	☑	×	×	☑ <sup>7</sup>	☑ <sup>7</sup>	☑ <sup>7</sup>	×	×	☑	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■	☑	■	■	■	■	■	■	■	×	■	■	■						
Sony	α850	Full-frame	—	×	☑	×	×	☑ <sup>7</sup>	☑ <sup>7</sup>	☑ <sup>7</sup>	×	×	☑	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■	☑	■	■	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	×	■ <sup>1</sup>	■ <sup>1</sup>	■						
Sony	α7 series (mirrorless)	Full-frame		☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>	☑ <sup>4</sup>						
Sony	α100	APS-C	1.5x	■ <sup>1</sup>	☑	■ <sup>1</sup>	■ <sup>1</sup>	☑ <sup>7</sup>	☑ <sup>7</sup>	☑ <sup>7</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	☑	■	■	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■	■ <sup>1</sup>	■ <sup>1</sup>	■						
Sony	α700	APS-C	1.5x	■ <sup>1</sup>	☑	■ <sup>1</sup>	■ <sup>1</sup>	☑ <sup>7</sup>	☑ <sup>7</sup>	☑ <sup>7</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	☑	■	■	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■	■ <sup>1</sup>	■ <sup>1</sup>	■						
Sony	α200	APS-C	1.5x	■ <sup>1</sup>	☑	■ <sup>1</sup>	■ <sup>1</sup>	☑ <sup>7</sup>	☑ <sup>7</sup>	☑ <sup>7</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	☑	■	■	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■	■ <sup>1</sup>	■ <sup>1</sup>	■ <sup>1</sup>	■						



Digital SLR Cameras  (as of May 2017)		(Sensor)	Camera Crop Factor	Approximate	Model	Lens Description																									
		Format				SP 10-24mm F/3.5-4.5 Di-II	B005	A16	A14	C001	B011-S	B011-C	B018	B008	B016	A012	A007	A09	A010	A20	A001	A009	A17	A005	A011	F016	F012	F013	G005	27ZE	F017
Sony	A3500	APS-C	1.5X			☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>7</sup>	■	☒ <sup>7</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>
Sony	A5000 / A5100	APS-C	1.5X			☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>7</sup>	■	☒ <sup>7</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	
Sony	A6000 / A6300	APS-C	1.5X			☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>7</sup>	■	☒ <sup>7</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>	☒ <sup>4</sup>		

■ Compatible mount available. and compatible.      ✕ Not compatible. Image circle will not cover sensor dimensions.      ☒ Mount not available.

<sup>1</sup> "D" Compatible.      <sup>2</sup> AF motor is not built into lens. Lens functions only in manual focus mode when used with Nikon bodies without AF motors, e.g. D40, D40X, D60, D3000 series, D5000 series, etc.

<sup>3</sup> No AF Motor in body. Requires AF motor in lens for AF function.

<sup>4</sup> Sony NEX and “Mirrorless” Alpha models use Sony E-mount interchangeable lenses. Use of the Sony A-mount adaptor may permit use. Some use limitations may exist. Tamron’s Sony “E” mount lenses will fit and function on Alpha A-7 series models with some limitation, as these lenses were designed for APS-C Sensor size NEX and Alpha models.

<sup>5</sup> Nikon 1 models use 1Nikkor-mount interchangeable lenses. Use of Nikon FT1 mount adaptor may permit use. Some limitations may exist.

<sup>6</sup> Canon EOS-M uses Canon STM mount interchangeable lenses. Use of Canon EF-EOS M mount adapter may permit use. Some limitations may exist

<sup>7</sup> Tamron Di-III currently designates lenses for Sony E-mount for NEX model “mirrorless” ILC cameras AND Canon EOS-M ILC Cameras AND Micro Four Thirds Cameras from Olympus, Panasonic and others.

<sup>8</sup> Compatibility and/or use through third party adapters only

Additional compatibility and/or use limitations may exist. Please refer to current Tamron catalog for information.

■ Compatible mount available. and compatible.      ✕ Not compatible. Image circle will not cover sensor dimensions.      ☒ Mount not available.

<sup>1</sup> "D" Compatible.  
<sup>2</sup> AF motor is not built into lens. Lens functions only in manual focus mode when used with Nikon bodies without AF motors, e.g. D40, D40X, D60, D3000 series, D5000 series, etc.  
<sup>3</sup> No AF Motor in body. Requires AF motor in lens for AF function.  
<sup>4</sup> Sony NEX and “Mirrorless” Alpha models use Sony E-mount interchangeable lenses. Use of the Sony A-mount adaptor may permit use. Some use limitations may exist. Tamron’s Sony “E” mount lenses will fit and function on Alpha A-7 series models with some limitation, as these lenses were designed for APS-C Sensor size NEX and Alpha models.  
<sup>5</sup> Nikon 1 models use 1Nikkor-mount interchangeable lenses. Use of Nikon FT1 mount adaptor may permit use. Some limitations may exist.  
<sup>6</sup> Canon EOS-M uses Canon STM mount interchangeable lenses. Use of Canon EF-EOS M mount adapter may permit use. Some limitations may exist  
<sup>7</sup> Tamron Di-III currently designates lenses for Sony E-mount for NEX model “mirrorless” ILC cameras AND Canon EOS-M ILC Cameras AND Micro Four Thirds Cameras from Olympus, Panasonic and others.  
<sup>8</sup> Compatibility and/or use through third party adapters only  
 Additional compatibility and/or use limitations may exist. Please refer to current Tamron catalog for information.