

## Model Overview

10 mm    20 mm    40 mm    80 mm    160 mm    320 mm    640 mm

### Di III Lenses for mirrorless system cameras (Full Frame and APS-C) / For Sony

**20mm F/2.8**  
Di III OSD M1:2

**24mm F/2.8**  
Di III OSD M1:2

**35mm F/2.8**  
Di III OSD M1:2

**17-28mm F/2.8**  
Di III RXD

**28-75mm F/2.8**  
Di III VXD G2

**28-200mm F/2.8-5.6**  
Di III RXD

**35-150mm F/2-2.8**  
Di III VXD

**70-180mm F/2.8**  
Di III VXD

**70-300mm F/4.5-6.3**  
Di III RXD

**150-500mm F/4.5-6.3**  
Di III RXD

### Di III-A Lenses for mirrorless system cameras (APS-C) / For Sony/Fujifilm

**11-20mm F/2.8**  
Di III-A RXD

**17-70mm F/2.8**  
Di III-A VC RXD

**18-300mm F/3.5-6.3**  
Di III-A VC VXD

### Di Lenses for DSLR cameras (Full Frame and APS-C) / For Canon/Nikon

**35mm F/1.4**  
Di USD

**SP 24-70mm F/2.8**  
Di VC USD G2

**SP 70-200mm F/2.8**  
Di VC USD G2

**100-400mm F/4.5-6.3**  
Di VC USD

**SP 150-600mm F/5-6.3**  
Di VC USD G2

### Di II Lenses for DSLR cameras (APS-C) / For Canon/Nikon

**18-200mm F/3.5-6.3**  
Di II VC

**18-400mm F/3.5-6.3**  
Di II VC HLD

The Di-III and Di series lenses can be used on both full-frame and APS-C cameras. In the Di-III-A series, the 18-300mm F/2.8 is also available with mount for Fujifilm X-Mount. TAMRON lenses for digital SLR cameras (Di and Di II) can also be used on the adapters. TAMRON lenses for digital SLR cameras (Di and Di II) can also be used on Canon and Nikon mirrorless system cameras

# TAMRON